Multiplexers

Dov Kruger

Department of Electrical and Computer Engineering Rutgers University

September 24, 2024








Multiplexers

- Multiplexers (MUX) are digital switches
- Select one of many inputs and route it to a single output
- Used to route data, control, and address signals in digital systems
- Think of a mux as a multi-position switch






Multiplexer Symbol





2-to-1 Multiplexer Schematic



S	D1	D0	Y
0	X	D0	D0
1	D1	X	D1



2-to-1 Multiplexer in Verilog

```
module mux2to1(
    input wire d0, d1, // 8-bit input data
    input wire sel, // Select line
    output reg y // 8-bit output
);
always \mathbb{Q}(*) begin
    if (sel)
      v = d1:
    else
        y = d0;
end
endmodule
```



2-to-1 Multiplexer in Verilog

module mux2to1(

endmodule


Verilog implementation of a 2:1 multiplexer

input wire d0, d1, // 8-bit input data

• Uses a ternary operator for selection



Multiplexer Schematic



		D3		1	1	
0	0	X X X D3	X	X	D0	D0
0	1	Х	Х	D1	Х	D1
1	0	Χ	D2	Х	Х	D2
1	1	D3	X	X	X	D3



Multiplexer Schematic

- Select one of the inputs based on the select lines
- The select lines determine which input is connected to the output



4-to-1 Multiplexer in Verilog

rendmodule

```
module mux4to1(
    input wire [3:0] d, // 4 1-bit inputs
    input wire [1:0] sel, //2-bit select line
                           // 1-bit output
    output reg y
always \mathbb{Q}(*) begin
    case (sel)
        2'b00: y = d[0];
        2'b01: y = d[1];
        2'b10: y = d[2];
        2'b11: y = d[3];
        default: y = 1'bx; // undefined for invalidation
    endcase
end
```